



pannier rack for speed

big cat HPV, LLC
720 Business Park Blvd Ste 22
Winter Garden, FL 34787

PARTS LIST:

- 01 - Pannier Rack Assembled
- 02 - Mounting Brackets with spacers



The pannier rack comes assembled and ready to mount to your trike.

- 01 - Remove the mounting bolts from the mounting brackets. Make note of the configuration. You will be replacing them in step 3.
- 02 - Slide the mounting brackets over the frame of your trike using the rack as a guide for position. You may need to loosen some straps on the seat mesh to work with the brackets.
- 03 - Replace the bolts, washers, nuts, and spacers on the brackets like they were in the box.



- 04 - Lay the slotted brackets on the rack on top of the spacers and loosely fasten one screw per side to hold the rack in place while you work.
- 05 - Using the M5x10 socket head cap screws provided, attach the ends of the support stays to the frame in the holes provided above the dropouts.
- 06 - Using the remainder of the bolts, washers, and nuts you removed in step 1, finish attaching the rack to the mounting brackets.



Note: We recommend applying Loctite #2440 medium strength removable blue, to the threads of the screws on the mounting bracket. This will help prevent the screws from loosening due to vibration and causing your rack to become less rigid.

- 7 - Level the rack by adjusting the length of the support stays and tighten all bolts, including the clamps on the support arms.

